

Babygym by Avenlur



⚠ WARNING

Possible entanglement injury. Keep out of baby's reach. Remove mobile from crib or playpen when baby begins to push up on hands and knees.

OPERATION INSTRUCTIONS

1. Please install and use correctly
2. A mobile is intended for visual stimulation and is not intended to be grasped by the child.
3. If attached to the crib or playpen, remove when baby begins to push up on hands and knees. If so designed, mount on wall or ceiling clearly out of a standing baby's reach.
4. If mounted on a wall or ceiling, install the mobile clearly out of a standing baby's reach.
5. Always attach all provided fasteners (strings, straps, clamps, etc.) tightly to a crib or playpen according to the instructions. Check frequently.
6. Do not add additional strings or straps to attach to a crib or playpen.

CONTACT US BEFORE ASSEMBLY

If you have assembly questions or if you need parts
whether they are missing or damaged

Call us at 888-697-3931 or email us at

info@Avenlur.com

Babygym by Avenlur

