avenlur

lvy by Avenlur



A WARNING

- Read all instructions before assembly and use of the stationary activity center.
- Keep instructions for future use.
- Do not use the stationary activity center if it is damaged or broken.



WARNING

WARNING: DEVELOPMENTAL USAGE CRITERIA

Start of Use: This product may only be used when the child has achieved the developmental milestone of holding their head up unassisted, as a minimum requirement.

Discontinuation of Use: Cease using this product as a stationary activity center immediately when the child begins to walk unassisted.

Critical Reminder: Failure to adhere to these developmental criteria (e.g., using the product before the child meets the minimum developmental level, or continuing use after the child exceeds the applicable stage) may expose the child to safety hazards such as falls, bumps, or other injuries.

FALL HAZARD

Babies can FALL from product resulting in head injuries.

- **NEVER** leave child unattended. Always keep child in view while in product or product description.
- NEVER use near stairs.
- To avoid tip over, place product on a flat, level surface.

STRANGULATION HAZARD

Strings can cause STRANGULATION.

- DO NOT place items with a string around child's neck, such as hood strings or pacifier cords.
- DO NOT suspend strings over product or attach strings to toys.

Assemble steps



Stage 1

page 1


For ages 0-6M



Stage 2
From page 3 to page 10
For ages 6M to 2Y



Stage 3
From page 11 to page 14
For ages 18M to 5Y




IVY MAT - SOLD SEPARATELY

page 2


For ages 0M+




IVY ACTIVITY TABLE SOLD SEPARATELY
From page 15 to page 19
For ages 18M to 5Y




1 ×1 22.0in




×1 23.5in




3 ×3 27.5in




4 ×1 13.5in



(5) ×1 14.0in









































































19×1








21) ×1














Note: After assembling Part 22, please be sure to peel off the scratch-resistant film on the mirror to prevent children from ingesting it.






IVY MAT - SOLD SEPARATELY






Thread part 14 onto the strap.




Stage 2

You need to take away the mat and remove Part 22.





04-1

Remove screws (E) and nuts (F).




When installing, please attach the short side of part 16 at the bottom.







\bigoplus	4mm	2
	M6×10	18
F	M6×15	18


Install part 5 together with part 4, and pay attention to their orientation.






After putting them together, fasten the clips around the inner circle.







Install Section $\boxed{06\text{-}1}$ together with part $\boxed{1}$, and make sure the clips at the bottom are securely fastened. Don't need to worry about the orientation of Section $\boxed{06\text{-}1}$, as it can rotate after installation.


08-1



Please install Part 6 in the direction specified in the instruction manual.







Step 1: Pass Part 6 through the hole on top of Part 3.

Step 2: Pass Part 6 back through the middle hole of Part 6, and install Part 14 into it.


Installation and adjustment of the spring strap


To help you quickly understand the installation and adjustment of the spring strap, we will mark the strap in red in some steps.

Installation of the spring strap





Need help? Scan the QR code to watch the instructional video.






Step 1: Fold the red part of the strap to make it the same as the image on the right.









Step 2: Pinch it tightly and thread it through the hole.

Step 3: Open the washer to complete the installation.


Removal of the strap



Step 1




Step 2



Step 3

- Step 1: Gently lift the toy board and fold the red part of the strap below upwards to the left, making it the same as the illustration.
- Step 2: Pinch it tightly and pull it through the hole.
- Step 3: The removal is complete.

Height Adjustment



There are 6 gears available for height adjustment, and please use it together with Part (14).







Step 1: After selecting the appropriate gear, thread the strap through the hole.

Step 2: Stretch the strap open and tuck Part 14 into it.





Note: After assembling Part 11, please be sure to peel off the scratch-resistant film on the mirror to prevent children from ingesting it.





11-1








ensure part 9 fits into its

screws (C).


corresponding hole, then tighten









Remove part 14 from Section 15-1B.









15-1B

Remove the bottom screws.



18-1


Remove the bottom screws.





H 4mm 2


19-1

Remove part 15.













Please install the toy in the designated position and press it firmly to prevent loosening.






IVY ACTIVITY TABLE - SOLD SEPARATELY








Remove parts 18, 19, 20, and 21.


21-2


Remove (E) screws and (F) nuts.





21-3


Take out part 3 in the direction of the arrow.











Install Section 21-1B according to the method on Page 9

21-1B

